



For quick start, follow the steps below:


Step 1: In Cube IDE, choose the RUN menu item, the Debug Configurations:




Step 2: A dialog box will launch. Click the 'new configuration' icon:




Step 3: on the Main tab, select your project and the .elf object file:




Step 4: Ensure your Nucleo is connected to your PC, then click the 'Debugger' tab:




Step 5: Select the debugger, click the ST-LINK check box, and scan. Then the serial number of your Debugger. I would recommend doing one at a time. Leave the second disconnected for now.



Step 6: Click the 'Run' button.



Step 7: An editor will open and there will be an arrow next to the first line of executable code.



Click the green arrow to run it. The Red square will terminate it, and the combination icon will reload the code. Under the run menu you will find a restart that issues a reset to the device.